

Product order codes

headsupports

- Head rest HEADREST
- Neck roll NECKROLL
- Neck curve NECKCURVE

backoptions

- Reactive lumbar support /3LUM
- Thoracic support /THOR
- Vertical support (Left/right or both) VSL / VSR
- Memory foam back MFB
- Upholstered outer back cover UOC

armoptions

- Height adjustable arms - PU pad HAA
- Width adjustable arms ADAPTW
- Rotating arms WSARM
- HAA arms + retractable arm pads 1234
- Mobile support arms (pair) MSA
- HAA arms + lateral movement pads 1233
- Short arm pads ADAPTS
- Gel arm pads GEL

seatoptions

- Internal sprung seat SPR
- Extra small seat SMS
- XL seat EXSEAT
- XXL seat EXXSEAT
- Coccyx cut out /CC
- Inflatable thigh support /TS
- Reduced seat width or length RED

gaslifts

- Gaslift 1 GL1
- Gaslift 2 GL2
- Gaslift 3 GL3

bases

- Alu base /CHR
- Brake loaded castors (set of 5) BLC
- Brake unloaded castors (set of 5) BUC
- Lockable castors (set of 5) LOC
- Soft wheel castors (set of 5) SWC

footring

- Standard footring FTR
- 50% footplate HFP

specialist

- Pneumatic movement lock MLOCK
- Swivel lock SLOCK
- Massage chair MASSAGE
- Leg rest or double leg rest LEGREST/ DLEGREST

because people are not made to standard specifications...

...neither are our chairs



your local ergochair distributor is...

The Back Centre Ltd
Erme Court
Leonards Road
Ivybridge
Devon, PL21 0SZ
t: 01752 893414
f: 01752 698339
e: sales@backcentre.co.uk
w: www.backcentre.co.uk

Ergochair Ltd

t: 01454 329210
 f: 01454 329266
 e: sales@ergochair.co.uk
 w: www.ergochair.co.uk




adaptations

your full range of seating options

adaptations

Please see side flap for product order codes.




headsupports



upholstery

• ESD Anti-static option available

inflatableaircells



backoptions

- Reactive lumbar support
- Thoracic support
- Vertical support (L/R or both)
- Memory foam back
- Upholstered outer back cover

armoptions

gaslifts

Please refer to our Retail Price List for approximate seat heights.

- Gaslift 1
- Gaslift 2
- Gaslift 3

bases

- Aluminium base
- Brake loaded castors (set of 5)
- Brake unloaded castors (set of 5)
- Lockable castors (set of 5)
- Soft wheel castors (set of 5)
- Tower glide (set of 5)

splitseat

The split seat can be fitted to any of the Ergochair Specialist Chairs. The flaps are lockable in 10 deg. increments to a maximum deflection of 40 deg.



alubase



legrest

seatoptions

- Sprung seat
- Split seat
- Coccyx cut out
- Inflatable thigh support
- Extra large seat
- Extra small seat



50% footplate



footring

massagespots

- Available with individual dual massage points (as shown)
- Programmable handset with wave or pulse modes (intensity and speed adjustable)
- Pads can be positioned anywhere on the chair
- Supplied on static glides. Appropriate power source required - supplied with transformer and 3.5 M cable
- Also available with variable intensity heat pads (3)

fabricoptions

We can source a highly versatile range of fabric and colour options to suit your specific working environment.



t: 01454 329210
f: 01454 329266
e: sales@ergochair.co.uk
w: www.ergochair.co.uk